



TRAFICON
TRAFFIC VIDEO DETECTION

TrafiCam





Overview TrafiCam Kits & Components USA - Canada

Document Name :	Overview TrafiCam Kits & Components USA-Canada
Version Number :	7
Author:	Robin Collaert
Function:	Product Manager
Date:	29-06-2009




Total Number of Pages: 4





1 Traficam kits

Ref. No	Description	Image
14-6030	<p>Traficam 1/3" 3,0mm (103°) for <u>TI (9 wires)</u></p> <ol style="list-style-type: none"> 1. Traficam wide angle 2. Mounting bracket (mounting device, 4 tube clamps, 8 bolt/screw combinations, tube) 3. Hexagonal screw drivers (2 pieces) 4. Bootlace ferrules (25x) 5. Cable (5ft STP with 10 wires + shielding) 6. CD-ROM (with manual, Traficam detection firmware and Traficam PC Tool) 	
14-6031	<p>Traficam 1/3" 8,0mm (39°) for <u>TI (9 wires)</u></p> <ol style="list-style-type: none"> 1. Traficam narrow angle 2. Mounting bracket (mounting device, 4 tube clamps, 8 bolt/screw combinations, tube) 3. Hexagonal screw drivers (2 pieces) 4. Bootlace ferrules (25x) 5. Cable (5ft STP with 10 wires + shielding) 6. CD-ROM (with manual, Traficam detection firmware and Traficam PC Tool) 	
15-6030	<p>Traficam 1/3" 3,0mm (103°) for <u>1TI or 4TI</u></p> <ol style="list-style-type: none"> 1. Traficam wide angle 2. Mounting bracket (mounting device, 4 tube clamps, 8 bolt/screw combinations, tube) 3. Hexagonal screw drivers (2 pieces) 4. Bootlace ferrules (25x) 5. Cable (5ft STP with 4 wires + shielding) 6. CD-ROM (with manual, Traficam detection firmware and Traficam PC Tool) 	
15-6031	<p>Traficam 1/3" 8,0mm (39°) for <u>1TI or 4TI</u></p> <ol style="list-style-type: none"> 1. Traficam narrow angle 2. Mounting bracket (mounting device, 4 tube clamps, 8 bolt/screw combinations, tube) 3. Hexagonal screw drivers (2 pieces) 4. Bootlace ferrules (25x) 5. Cable (5ft STP with 4 wires + shielding) 6. CD-ROM (with manual, Traficam detection firmware and Traficam PC Tool) 	




2 Interface

Ref. No	Description	Image
10-6025	TI (9 wires) Interface for connection to 1 TrafiCam, 9 wires + shielding, maximum 4 outputs	
10-6028	1TI Interface for connection to 1 TrafiCam, 4 wires + shielding, maximum 4 outputs	
10-6027	4TI Interface for connection to 1-4 TrafiCams, 4 wires+ shielding, maximum 16 outputs	

3 Optional Issues

Ref. No	Description	Image
10-6016	RS232-485 converter + Null-modem cable (1,8m) Cables for setup of <u>TI (9 wires)</u> with PC	
LEA050923	USB/A – USB/B converter Cable for setup of <u>1TI or 4TI</u> with PC	

4 TrafiCam Wireless 915 MHz (USA, Canada)

Ref. No	Description	Image
10-6034	<p>TrafiCam Wireless 915MHz 1/3" 3,0mm (103°)</p> <ol style="list-style-type: none"> 1. TrafiCam Wireless with wide field of view 2. Mounting bracket 3. CD-ROM with configuration software and manuals 4. Hex key (2 pieces) 5. Cable (5ft STP with 4 wires + shielding) 	
10-6035	<p>TrafiCam Wireless 915MHz 1/3" 8,0mm (39°)</p> <ol style="list-style-type: none"> 1. TrafiCam Wireless with narrow field of view 2. Mounting bracket 3. CD-ROM with configuration software and manuals 4. Hex key (2 pieces) 5. Cable (5ft STP with 4 wires + shielding) 	
10-6027	<p>4TI interface</p> <p>Interface boards for connection to 1 TrafiCam Wireless sensor, using 4-wired cable, providing 16 outputs (i.e. 4 outputs per TrafiCam Wireless sensor) USB connection to go to portable PC. (USB-A/USB-B cable: ref. LEA050923)</p>	
LEA050923	<p>USB A – USB B converter</p> <p>For connection of <u>1TI</u> or <u>4TI</u> interface board to portable PC over USB</p>	